

PRODUCT INFORMATION

DUNLOP PROCOVER UNCOUPLING MAT

DESCRIPTION

DUNLOP PROCOVER UNCOUPLING MAT gives you the confidence to tile onto difficult floors which are at risk from stresses and accommodate lateral movement for the tile installation when used as a system, with a recommended DUNLOP flexible cement based adhesive such as DUNLOP SET FAST PLUS FLOOR & WALL TILE ADHESIVE. Ideal for tiling internal floors such as timber and new sand & cement screeds. Suitable for bathrooms and kitchens with most types of ceramics, natural stone and mosaics.

WHAT IT MEANS FOR YOU

- Ideal for tiling onto timber floors and new sand & cement screeds
- Suitable for use over underfloor or undertile heating when used with a suitable DUNLOP Floor Levelling Compound such as DUNLOP FIBRE REINFORCED FLOOR LEVELLER
- Prevents reflective cracking caused by shrinkage cracks, board junctions and lateral movement
- Simple and fast to install
- 1mm mat depth does not increase heights
- Pre-marked gridlines to help cutting
- Tape not required
- In wet duty areas, apply DUNLOP SHOWER WATERPROOFING KIT, no primer required onto the mat.

DIRECTIONS FOR USE

Point 1

Always prepare the background to the requirements of the substrate.

Point 2

Ensure the floor is sound and free from all loose particles, dust and any other barriers to adhesion. The floor should be flat, even to apply the DUNLOP PROCOVER UNCOUPLING MAT. If required use a suitable DUNLOP Floor Levelling Compound. Roll the 5 meter mat out on the floor area and cut to required size using scissors or utility knife. The printed gridlines will help ensure accurate sizing.

Point 3

Move the mat to one side and spread a layer of suitable DUNLOP tile adhesive, such as DUNLOP SET FAST PLUS FLOOR & WALL TILE ADHESIVE, onto the floor using a 4mm notched trowel.

Point 4

Smooth the mat into the wet adhesive, ensure any edges are butted up but do not overlap the edges of the mat. It is important to apply the mat within the working time of the adhesive. Any break or join in the background must be married with a break in the mat.

Point 5

The mat must be fully pressed into the tile adhesive, this can be achieved using a trowel or float over the surface to gently push out any air pockets. Remove any tile adhesive which has extruded through the joints.

Point 6

Once the mat is in place, you can immediately begin tiling using a suitable tile adhesive such as DUNLOP SET FAST PLUS FLOOR & WALL ADHESIVE or DUNLOP LARGE FORMAT & NATURAL STONE TILE ADHESIVE. Spread the over the mat using a suitable thick bed solid bed trowel and lay the tiles as normal. The total thickness of adhesive on top of the mat must not exceed 6mm.

PRODUCT INFORMATION

STORAGE & SHELF LIFE

12 months under normal dry conditions. Protect from frost and damp.

COVERAGE

5 square meter roll

Please refer to the Material Safety Data Sheet for further information on health and safety issues.

TECHNICAL ADVISORY SERVICE

For free expert guidance on the use of this product or any aspect of ceramic tiling telephone the **TECHNICAL ADVISORY SERVICE** on: **Tel:** 01782 591120 **Fax:** 01782 591121.

Note: The customer must verify the suitability of any information, opinion, recommendation or advice ("Information") provided by the Company for the particular application for which any goods are intended to be used and the Company accepts no liability (whether in contract tort, or otherwise) whatsoever for any loss, damage, or expense arising from the misuse of any information it supplies nor for the use of any information in or for applications which are unsuitable or inappropriate. Building Adhesives Ltd operates a continuous research and development programme and reserves the right to alter or update information from time to time.